

RECOMMENDED FIXINGS

Westcoast recommend the following materials and suppliers.

Fixing straps, sometimes referred to as 'VIMO' type lugs.

(See drawing details on page 40)

Also general metal fabrication services
– cill flashings, flitch plate etc.

NEWBREL LTD

Amber Way, Gainsford Drive, Halesowne Industrial Park, West Midlands B62 8BQ
Tel: 0121 585 2745 www.newbrel.com

DARNBRIDGE LIMITED

Unit 20, Ffordd Las, Rhyl, LL18 2QD
Tel: 01745 356840 www.darnbridge.co.uk

FINISH ARCHITECTURAL LTD

215 Tame Road, Witton, Birmingham B6 7DQ
Tel: 0121 327 0523 www.finisharchitectural.co.uk

**Silicone Sealant
Arbosil LM, 1090, 1090
or similar**

ADSHEAD RATCLIFFE & CO. LTD

Derby Road, Belper, Derbyshire DE56 1WJ
Tel: 01773 826661 www.arbo.co.uk

**Impregnated Sealing Tape
Compriband 600**

TREMCO ILLBRUCK LIMITED

Coupland Road, Hindley Green, Wigan WN2 4HT
Tel: 01942 251400 www.illbruck.com/en_GB

**PU expanding foam
FM230 Pro Foam**

TREMCO ILLBRUCK LIMITED

Coupland Road, Hindley Green, Wigan WN2 4HT
Tel: 01942 251400 www.illbruck.com/en_GB

**PU expanding foam
GREAT STUFF™ PRO**

DOW CHEMICAL COMPANY LTD

Dow Building Solutions, Diamond House, Lotus Park Kingsbury Crescent, Staines TW18 3AG
Tel: 020 3139 4000 www.building.dow.com

**Membranes
Siga Fentrim 2, 20**

AIRTIGHTTAPES.CO.UK

1 Sarah Court Piperell Way, CB9 8PA Haverhill
Tel: 01440 710747 www.airtighttapes.co.uk

Foam Backing rod

STICKY PRODUCTS

Markham House, Atkinsons Way, Foxhills Ind. Park, Scunthorpe, North Lincolnshire DN15 8QJ
Tel: 01724 749020 www.stickyproducts.co.uk

Cover Caps

WESTCOAST WINDOW SYSTEMS LTD

Unit 8 Brickfields Business Park, Old Stowmarket Road, Woolpit, Bury St Edmunds, Suffolk IP30 9QS
Tel: 01359 241944 www.westcoastwindows.com

Nylon Packers

WINDOW WARE (WEB BASED)

Telford Way, Cross Park, Bedford MK42 0PQ
Tel: 01234 242 724 www.windowware.co.uk



TYPICAL FIXING STRAP

Westcoast Windows suggest a strap of 2.5-3mm thick mild galvanised steel, 10mm cranked with 2 no. pre-punched holes (6mm diameter) for attachment to the timber frame of the profile.

Ideally, locations of holes 20mm from edge of timber frame and a minimum 25mm apart from another and staggered.

Strap length bespoke to suit project but usually 100mm minimum and increments of 50mm thereafter should suit most situations.

